

Opera Bit / Opera iControl - Split-spindle





Description

Split-spindle to use the lock with independent movement both for internal and external sides.

Fastening

To install the double element, please divide the two parts using a 2,5 mm Allen key in to the internal screw, apply them to the lock and fasten them once again.



ATTENTION: the use of the double element requires the handle fastening with threaded screws and suitable rosette. Don't fasten the handle only to the square.

Order specifications

Article	Material	A	B
B59901.47.57	steel	47	57
B59901.62.72	steel	62	72